


Moulinex


**DD408D71/600**  
700W




Moulinex

**DD408D71/600**  
700W

MS-0678937




MS-0612117



MS-5945460



MS-0568182




MS-0678747



Moulinex

DD408D71/600  
700W


MS-0695660




MS-0695658



MS-0695547



MS-4946320



MS-069565D



MS-0695591



MS-0695652

MS-0695638



MS-0695593

