


Moulinex

# HF80CB10/702


1550W



Moulinex

# HF80CB10/702

1550W




Moulinex

# HF80CB10/702

1550W

MS-8030000748



MS-8030000747

MS-0A19114

XF380E12




MS-0A19157

MS-8030000417

MS-7232601568

MS-8080017770

MS-8080017297



MS-8080017769


MS-8080017297



MS-0A19025



MS-8030000307




Moulinex

HF80CB10/702  
1550W

# OPTION

XF38J010

MS-8030000889



MS-0A19336



MS-0A19337



MS-0A19338



MS-0A19339




Moulinex

HF80CB10/702  
1550W

# OPTION


## XF383110

MS-0A19351




MS-0A19350

MS-0A19114



MS-0A21440



MS-0A21443



MS-0A21447



MS-0A21446




MS-0A21445





Moulinex

**HF80CB10/702**  
1550W




Moulinex

HF80CB10/702  
1550W

# OPTION

XF38AE10



MS-8030000309


MS-8030000310

Moulinex

HF80CB10/702  
1550W

# OPTION

XF387E10





Moulinex

HF80CB10/702  
1550W

# OPTION

XF389010

MS-8030000889

